

# 1984 Various 501

<b>Year:</b>	1984
<b>Model:</b>	Various
<b>Series:</b>	501
<b>Blower:</b>	1hp 120V motor 6500-107
<b>Board:</b>	Unavailable, convert to 6UR circuit board 6500-476
<b>Transformer:</b>	120V - 12V 6560-278
<b>Heater:</b>	Stainless Steel Manifold, bolt-in element Manifold: 6000-002, Element: 6560-252
<b>Panel:</b>	Unavailable, convert to 605 control panel 6500-516
<b>Pump #1:</b>	3/4hp 2sp 120V Sta-Rite Maxi-Glas 6500-192
<b>Pump #2:</b>	N/A
<b>Temp Sensor:</b>	White plug connector, transistor type, resistance cannot be checked. 6560-423
<b>Hi-Limit:</b>	30" manual switch 6560-230
<b>Weir Gate:</b>	Sliding weir gate 9800-104
<b>Timer:</b>	No equipment timer unless converted to 6UR 6560-700
<b>Sanitizer:</b>	No standard ozone, no standard circulation pump
<b>Therapy Jets:</b>	Various
<b>Whirlpool:</b>	Various
<b>Therapy Seat:</b>	Various
<b>Foot Jets:</b>	Various
<b>Air Controls:</b>	Various
<b>Diverter:</b>	Various
<b>Air Injectors:</b>	Various
<b>Filter:</b>	Various

# 1984 Various 601

<b>Year:</b>	1984
<b>Model:</b>	Various
<b>Series:</b>	601
<b>Blower:</b>	1hp 120V motor, old one may have been an Anson blower 6500-107
<b>Board:</b>	6UR circuit board 6500-476
<b>Transformer:</b>	120V - 12V 6560-278
<b>Heater:</b>	Stainless Steel Manifold, screw-in element Manifold: 6000-002, Element: 6560-025
<b>Panel:</b>	605 control panel 6500-516
<b>Pump #1:</b>	3/4hp 2sp 120V Sta-Rite Maxi-Glas 6500-192
<b>Pump #2:</b>	N/A
<b>Temp Sensor:</b>	White plug connector, transistor type, resistance cannot be checked. 6560-423
<b>Hi-Limit:</b>	Peppy hi-limit 6560-221
<b>Weir Gate:</b>	Sliding weir gate 9800-104
<b>Timer:</b>	Had Paragon timer, must change to 120V Grasslin timer kit 6560-865
<b>Sanitizer:</b>	No standard ozone, no standard circulation pump
<b>Therapy Jets:</b>	Various
<b>Whirlpool:</b>	Various
<b>Therapy Seat:</b>	Various
<b>Foot Jets:</b>	Various
<b>Air Controls:</b>	Various
<b>Diverter:</b>	Various
<b>Air Injectors:</b>	Various
<b>Filter:</b>	Various

# 1984-1985

## Various 602

<b>Year:</b>	1984-1985
<b>Model:</b>	Various
<b>Series:</b>	602
<b>Blower:</b>	1hp 120V motor 6500-107
<b>Board:</b>	6UR circuit board 6500-476
<b>Transformer:</b>	120V - 12V 6560-278
<b>Heater:</b>	Stainless Steel Manifold, bolt-in element Manifold: 6000-002, Element: 6560-252
<b>Panel:</b>	605 control panel 6500-516
<b>Pump #1:</b>	3/4hp 2sp 120V Sta-Rite Maxi-Glas 6500-192
<b>Pump #2:</b>	N/A
<b>Temp Sensor:</b>	White plug connector, transistor type, resistance cannot be checked. 6560-423
<b>Hi-Limit:</b>	30" manual switch, THIS HAS LIVE VOLTAGE GOING THROUGH IT! 6560-230
<b>Weir Gate:</b>	Sliding weir gate 9800-104
<b>Timer:</b>	Had Paragon timer, must change to 120V Grasslin timer kit 6560-865
<b>Sanitizer:</b>	No standard ozone, no standard circulation pump
<b>Therapy Jets:</b>	Various
<b>Whirlpool:</b>	Various
<b>Therapy Seat:</b>	Various
<b>Foot Jets:</b>	Various
<b>Air Controls:</b>	Various
<b>Diverter:</b>	Various
<b>Air Injectors:</b>	Various
<b>Filter:</b>	Various

# 1985

## Various 552/553

<b>Year:</b>	1985
<b>Model:</b>	Various
<b>Series:</b>	552/553
<b>Blower:</b>	1hp 120V motor 6500-107
<b>Board:</b>	Unavailable, convert to 6UR circuit board 6500-476
<b>Transformer:</b>	120V - 12V 6560-278
<b>Heater:</b>	Stainless Steel Manifold, bolt-in element Manifold: 6000-002, Element: 6560-252
<b>Panel:</b>	Unavailable, convert to 605 control panel 6500-516
<b>Pump #1:</b>	3/4hp 2sp 120V Sta-Rite Maxi-Glas 6500-192
<b>Pump #2:</b>	N/A
<b>Temp Sensor:</b>	White plug connector, transistor type, resistance cannot be checked. 6560-423
<b>Hi-Limit:</b>	15" manual switch 6560-235
<b>Weir Gate:</b>	Sliding weir gate 9800-104
<b>Timer:</b>	No equipment timer, unless converted to 6UR 6560-700
<b>Sanitizer:</b>	No standard ozone, no standard circulation pump
<b>Therapy Jets:</b>	Various
<b>Whirlpool:</b>	Various
<b>Therapy Seat:</b>	Various
<b>Foot Jets:</b>	Various
<b>Air Controls:</b>	Various
<b>Diverter:</b>	Various
<b>Air Injectors:</b>	Various
<b>Filter:</b>	Various